

# Dr. Fixit Crack-X Shrinkfree



## ONE TIME SHRINK-FREE FILLER FOR PLASTER CRACKS

### Description

**Dr. Fixit Crack-X Shrinkfree** is composed of best quality polymer, properly selected fillers & additives. It is fast drying flexible, very light weight, soft putty like material used for filling cracks in plastered surfaces because it is 100% shrink free, water resistant after drying & bonds strongly to cementitious substrates.

### Areas of Application

- Internal & external surface cracks on plaster upto 10 mm width.

### Features & Benefits

- **Shrinkage** - Non-shrink even after curing, prevents from cohesive & adhesive failure on exposure.
- **Application** - Applied as one time filling (does not require second time application, as required in other acrylic sealants).
- **User friendly** - One pack, very soft paste, easily applicable by fingers or putty knife.
- **Sagging** - Non-sag nature helps in filling of vertical & overhead cracks.
- **Sanding** - No sanding is required.
- **Staining** - Does not migrate any liquid component into concrete surface thus prevents staining.
- **Adhesion** - Excellent adhesion to cementitious surfaces prevents water leakages through the cracks.
- **Durability** - UV & weather resistance properties increases the life expectancy of the surface.
- **Saving** - Saves time, labour & energy.
- **Paintability** - Easily paintable after 5-6 hours of application.
- **Non-toxic** - It is non-toxic hence user friendly

### Method of Application

---

#### 1 SURFACE PREPARATION

- Surface must be free from dust, oil, grease, and loose particles, etc. Moisten the surface before applying Dr. Fixit Crack-X Shrinkfree.
- Fine hairline cracks must be widened upto 1 mm minimum and then filled.
- For filling Dr. Fixit Crack-X Shrinkfree on the internal surfaces, existing POP or painter's putty must be removed till plaster surface is exposed.

---

#### 2 APPLICATION

- Press Dr. Fixit Crack-X Shrinkfree firmly into the crack **ONE TIME ONLY** with a spatula or putty knife and level the surface.
- Handball application can also be used as per the convenience.
- Care must be taken to avoid formation of cavities or bubbles during application.
- Allow it to dry in ambient conditions for 5-6 hrs before painting. For best results 7 days air curing is advised.
- Further POP or painters putty application can be taken up once it is fully dry.

---

#### 3 CLEANING

- Clean tools & equipments by soap & water. Wash hands with soap & warm water.

# Dr. Fixit Crack-X Shrinkfree



ONE TIME SHRINK-FREE FILLER FOR PLASTER CRACKS

## Precautions & Limitations

- Not for cracks in POP or painter's putty.
- Not recommended to use under the rain.
- Not meant for structural cracks in concrete, slab, construction joints.
- Jet or Power washing on walls not advisable prior to application.
- During application below 10°C, drying time will be delayed.
- Container to be tightly closed after application.
- If filler compound becomes too dry, add potable water in ratio of 1 teaspoon in 250 ml of Dr. Fixit Crack-X Shrinkfree.

## Technical Information

PROPERTIES	RESULTS
Appearance	White paste
Base	Acrylic with specially added fillers
Drying time@ 30 °C, Hrs	5 - 6
Full curing time@ 30 °C, days	7
Specific gravity	0.0.26 +/-0.02

## Coverage

30-35 running meters/ltr at 5 mm depth.

## Packaging

1 ltr.

## Shelf Life & Storage

Shelf life is 12 months from the date of manufacturing. Store in cool & dry place, away from sun light.

## Health & Safety Precautions

- As with all chemical products, caution should always be exercised.
- Protective clothings, such as gloves and goggles, should be worn (see packaging for specific instructions).
- Treat any contact to the skin or eyes with fresh water immediately.
- Should any of the products be accidentally swallowed, do not induce vomiting but call for medical assistance immediately.
- Ensure the container is available for the medical attendant to examine any relevant instructions and contents details. Reseal all containers after use and ensure product is stored as instructed on the safety section of the labelling.

# Dr. Fixit Crack-X Shrinkfree



ONE TIME SHRINK-FREE FILLER FOR PLASTER CRACKS

## Other Product Categories Available

DR. FIXIT has wide range of Waterproofing & Construction chemicals which includes,

- Waterproofing Products
- Repair Products
- Sealants
- Flooring Products
- Exterior Coating Products
- Tile Fixing Range
- Concrete Admixtures
- Grouts



### Pidilite Industries Limited

Construction Chemicals Division  
Ramkrishna Mandir Road  
Post Box No. 17411  
Andheri (E) Mumbai 400059 INDIA  
Tel +91-22-2835 7000 • Fax +91-22-2835 7008  
website [www.doctor-fixit.com](http://www.doctor-fixit.com) • E-mail [drfixit@pidilite.com](mailto:drfixit@pidilite.com)  
**Toll Free No.: 1800-22-5502**

**DISCLAIMER** The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.